



* 工作频道频率: ↵

A: ↵

CH1:5740  CH2: 5760  CH3: 5780  CH4: 5800  ↵
CH5: 5820  CH6: 5840  CH7:5860  CH8:5880  ↵

↵

B: ↵

CH1:5725  CH2: 5745  CH3:5765  CH4:5785  ↵
CH5: 5805  CH6: 5825  CH7:5845  CH8: 5865  ↵

C: ↵

CH1:5733  CH2: 5752  CH3: 5771  CH4: 5790  ↵
CH5: 5809  CH6: 5828  CH7: 5847  CH8:5866  ↵

↵

D:↵

CH1: 5705  CH2:5685  CH3:5665  CH4: 5645  ↵
CH5: 5885  CH6: 5905  CH7:5925  CH8:5945  ↵





