
# RunCam User Manual




#### Instruction diagram




LED 1: Blue ——WiFi status light

- LED 2: Green ——Photo mode status light LED 3: Blue —— Video mode status light
- LED 4: Orange OSD Setup status light
- LED 5: Red Power Status Light: Blinking during operation (solid red while charging)




Warning: USB or 3 pin power interface only supports DC 5V power supply. Battery solder joints only support 4.2V lithium-ion battery.

### 5.8G Transmitter connection diagram




# WiFi module connection diagram




Warning: WiFi module is removable. Please insert the WiFi module in the correct direction! Otherwise the module could be damaged.

### MicroSD Card

Capacity up to 64GB; Please use high speed cards(Class10/UHS-I/UHS-II).



#### Lens module connection diagram



### Basic Camera Operation

Powering On/Off	Long press the Power/Shutter button
WiFi On/Off	Short press the WiFi/Mode Switch button
Mode Switching	After powering on, long press the WiFi/Mode Switch button to cycle through the three modes: Video/Photos/OSD settings.
Video Mode	Camera Status Light: <b>Blue (LED 3)</b> • Press the Power/Shutter button to start/stop recording.
Photo Mode	Camera Status Light: <b>Green (LED 2)</b> • Press the Power/Shutter button to capture photos.
OSD Setup Mode	Camera Status Light: Orange (LED 4) • Press the Power/Shutter button to move to a setting. • Press the WiFi/Mode Switch button to select. • Long press the WiFi/Mode Switch button to exit the menu.
Forced Shutdown	Simultaneously press the Power/Shutter button and WiFi/Mode Switch button.
Reset	In standby mode, press the WiFi/Mode Switch button three times in rapid succession (within 2 seconds). When resetting is complete, the status light (orange) blicks twice, and the camera automatically shuts dows.

#### App(Android | iOS)

Search 'RunCam App' on Google Play/Apple Store, or download on our website: runcam.com/download/runcamSplit

# Check Complete User Manual

Please visit: runcam.com/download/runcamSplit