

ID Set Up

The default physical ID for this sensor is 00. The ID number could be changed by FreeLink.

Notice: All FrSky Smart Port enabled sensors could daisy chain with each other through their Smart Port.

LED Status

The Battery and ESC should be connected to BAT port and ESC port correspondingly and make sure the polarity is correct. FrSky is not responsible for any damage caused by wrong polarity connection.

LED Status	S.Port	FBUS
Flash slowly	YES	NO
Flash quickly	NO	YES